




## Spare Parts

### Manhole Covers

# Oval Manhole Cover 510 x 410 Type LKD-LKDI

2



TD 500-017

## Oval Manhole Cover 510 x 410 Type LKD-LKDI


Pos.	Qty.	Denomination	LKD	LKDI	LKD	LKDI
			Low Frame 1.4301	High Frame 1.4301	Low Frame 1.4404	High Frame 1.4404
1	1	Frame (Period 9907- )	9612-6053-01	9612-6054-01	9612-6053-02	9612-6054-02
	1	Frame (Period -9907)	9611-70-2003	9611-70-082-0	9611-70-2144	9611-70-082-1
2	1	Cover (Period 9907- )	9612-6073-01	9612-6073-01	9612-6073-02	9612-6073-02
	1	Cover (Period -9907)	9611-70-2016	9611-70-2016	9611-70-2147	9611-70-2147
3	1	Hub (Period 9907- )	9612-6076-01	9612-6076-01	9612-6076-01	9612-6076-01
	1	Hub (Period -9907)	9611-70-2038	9611-70-2038	9611-70-2038	9611-70-2038
4	1	Toggle (Period 9907- )	9612-6065-01	9612-6066-01	9612-6065-01	9612-6066-01
	1	Toggle (Period -9907)	9611-70-2046	9611-70-2048	9611-70-2046	9611-70-2048
5	1	Trust collar (Period 9907- )	9612-6075-01	9612-6075-01	9612-6075-01	9612-6075-01
	1	Trust collar (Period -9907)	9611-70-2055	9611-70-2055	9611-70-2055	9611-70-2055
6	1	Top nut (Period 9907- )	9612-6077-01	9612-6077-01	9612-6077-01	9612-6077-01
	1	Top nut (Period -9907)	9611-70-2050	9611-70-2050	9611-70-2050	9611-70-2050
7	2	Screw (Period 9907- )	9611-99-1760	9611-99-1760	9611-99-1760	9611-99-1760
	1	Screw (Period -9907)	9611-70-2032	9611-70-2032	9611-70-2032	9611-70-2032
8	1	Suspension arm, left (Period 9907- )	9612-6047-01	9612-6048-01	9612-6047-01	9612-6048-01
	1	Suspension arm, left (Period -9907)	9611-70-2033	9611-70-087-0	9611-70-2033	9611-70-087-0
9	1	Clip (Period 9907- )	9611-99-0704	9611-99-0704	9611-99-0704	9611-99-0704
	1	Screw (Period -9907)	9611-70-2054	9611-70-2054	9611-70-2054	9611-70-2054
10	1	Nut (Period 9907- )	9611-99-1761	9611-99-1761	9611-99-1761	9611-99-1761
	3	Nut (Period -9907)	9611-70-0211	9611-70-0211	9611-70-0211	9611-70-0211
11	1	Seal NBR, black (Std.)	9611-70-2057	9611-70-2057	9611-70-2057	9611-70-2057
	1	Seal EPDM	9611-70-159-0	9611-70-159-0	9611-70-159-0	9611-70-159-0
	1	Seal FPM	9611-70-159-3	9611-70-159-3	9611-70-159-3	9611-70-159-3
	1	Seal Silicone (Q)	9611-70-159-2	9611-70-159-2	9611-70-159-2	9611-70-159-2
	1	Seal NBR, white	9611-70-159-1	9611-70-159-1	9611-70-159-1	9611-70-159-1

Recommended spare parts: Pos. 11.

TD 900-222

# Oval Manhole Cover 440 x 320 Type LKD

4



## Oval Manhole Cover 440 x 320 Type LKD


Pos.	Qty.	Denomination	1.4301	1.4404
1	1	Cover.....	9611-70-033-0	9611-70-033-1
2	1	Frame .....	9611-70-048-0	9611-70-048-1
3	1	Big mounting .....	9611-70-044-0	9611-70-044-0
4	1	Small mounting .....	9611-70-036-0	9611-70-036-0
5	1	Toggle.....	9611-70-034-0	9611-70-034-0
6	1	Handle, blue (Period 9907- ) .....	9611-70-067-2	9611-70-067-2
	1	Handle, green (Period -9907) .....	9611-70-067-0	9611-70-067-0
7	1	Seal - NBR, black (Std.) .....	9611-70-051-0	9611-70-051-0
	1	Seal - Silicone (Q).....	9611-70-051-1	9611-70-051-1
	1	Seal - EPDM.....	9611-70-051-2	9611-70-051-2
	1	Seal - NBR, white .....	9611-70-051-3	9611-70-051-3
8	2	Pin .....	9611-70-039-0	9611-70-039-0
9	4	O-ring .....	223403-02	223403-02
10	1	Capsule, blue (Period 9907- ).....	9611-70-064-4	9611-70-064-4
	1	Capsule, green (Period -9907) .....	9611-70-064-0	9611-70-064-0

Recommended spare parts: Pos. 7.

TD 900-223

# Oval Manhole Cover 440 x 320 Type LKD

6



## Oval Manhole Cover 440 x 320 Type LKD


Pos.	Qty.	Denomination	1.4301	1.4404
1	1	Cover .....	9611-70-077-0	9611-70-077-1
2	1	Frame .....	9611-70-030-0	9611-70-030-1
3	1	Toggle .....	9611-70-034-0	9611-70-034-0
4	1	Handle, blue (Period 9907- ) .....	9611-70-067-2	9611-70-067-2
	1	Handle, green (Period -9907) .....	9611-70-067-0	9611-70-067-0
5	1	Seal - NBR, black (Std.) .....	9611-70-051-0	9611-70-051-0
	1	Seal - Silicone (Q).....	9611-70-051-1	9611-70-051-1
	1	Seal - EPDM.....	9611-70-051-2	9611-70-051-2
	1	Seal - NBR, white .....	9611-70-051-3	9611-70-051-3
6	1	Capsule, blue (Period 9907- ).....	9611-70-064-4	9611-70-064-4
	1	Capsule, green (Period -9907) .....	9611-70-064-0	9611-70-064-0

Recommended spare parts: Pos. 5.

TD 900-224

# Oval Manhole Cover 450 x 350 Type LKD

8



TD 501-015



## Oval Manhole Cover 450 x 350 Type LKD


Pos.	Qty.	Denomination	With angle shaped frame and left-hand hinge		With flat frame and left-hand hinge	
			1.4301	1.4571	1.4301	1.4571
1	1	Frame 70x3.....	9612-1719-01	9612-1719-02		
	1	Frame 70x4.....	9612-1719-03	9612-1719-04		
	1	Frame 100x3.....	9612-1719-05	9612-1719-06		
	1	Frame 100x4.....	9612-1719-07	9612-1719-08		
	1	Frame 140x3.....	9612-1719-09	9612-1719-10		
	1	Frame 140x4.....	9612-1719-11	9612-1719-12		
	1	Frame 10x30.....			9612-1722-01	9612-1722-02
	1	Frame 12x30.....			9612-1722-03	9612-1722-04
2	1	Cover 3 mm (Period 9907- ).....	9612-6071-01	9612-6071-02	9612-6071-01	9612-6071-02
	1	Cover 3 mm (Period -9907).....	9612-1711-01	9612-1711-02	9612-1711-01	9612-1711-02
	1	Cover 4 mm (Period 9907- ).....	9612-6071-03	9612-6071-04	9612-6071-03	9612-6071-04
	1	Cover 4 mm (Period -9907).....	9612-1711-03	9612-1711-04	9612-1711-03	9612-1711-04
3	1	Seal, NBR (Standard) .....	9612-1710-04	9612-1710-04	9612-1710-04	9612-1710-04
	1	Seal, EPDM.....	9612-1710-03	9612-1710-03	9612-1710-03	9612-1710-03
	1	Seal, FPM .....	9612-1710-02	9612-1710-02	9612-1710-02	9612-1710-02
	1	Seal, Q.....	9612-1710-01	9612-1710-01	9612-1710-01	9612-1710-01
4	1	Suspension arm .....	9612-1715-01	9612-1715-01	9612-1715-01	9612-1715-01
5	1	Hub (Period 9907- ).....	9612-6076-01	9612-6076-01	9612-6076-01	9612-6076-01
	1	Hub (Period -9907).....	9612-1718-02	9612-1718-02	9612-1718-02	9612-1718-02
6	1	Nut.....	9611-99-1761	9611-99-1761	9611-99-1761	9611-99-1761
7	2	Screw .....	9611-99-1760	9611-99-1760	9611-99-1760	9611-99-1760
8	1	Toggle (Period 9907- ).....	9612-6067-01	9612-6067-01	9612-6067-01	9612-6067-01
	1	Toggle (Period -9907).....	9612-1707-02	9612-1707-02	9612-1707-02	9612-1707-02
9	1	Thrust plate (Period 9907- ).....	9612-6075-01	9612-6075-01	9612-6075-01	9612-6075-01
	1	Thrust plate (Period -9907).....	9612-1716-01	9612-1716-01	9612-1716-01	9612-1716-01
10	1	Clamping nut (Period 9907- ) ...	9612-6077-01	9612-6077-01	9612-6077-01	9612-6077-01
	1	Clamping nut (Period -9907) ...	9612-1708-02	9612-1708-02	9612-1708-02	9612-1708-02
11	1	Clip (Period 9907- ) .....	9611-99-0704	9611-99-0704	9611-99-0704	9611-99-0704

Recommended spare parts: Pos. 3.

TD 900-225

# Oval Manhole Cover 450 x 350 Type LKD

10



## Oval Manhole Cover 450 x 350 Type LKD


Pos.	Qty.	Denomination	With angle shaped frame without hinge		With flat frame without hinge	
			1.4301	1.4571	1.4301	1.4571
1	1	Frame 70x3.....	9612-1769-01	9612-1769-02		
	1	Frame 70x4.....	9612-1769-03	9612-1769-04		
	1	Frame 100x3.....	9612-1769-05	9612-1769-06		
	1	Frame 100x4.....	9612-1769-07	9612-1769-08		
	1	Frame 140x3.....	9612-1769-09	9612-1769-10		
	1	Frame 140x4.....	9612-1769-11	9612-1769-12		
	1	Frame 10x30.....			9612-1705-01	9612-1705-02
	1	Frame 12x30.....			9612-1705-03	9612-1705-04
2	1	Cover 3 mm (Period 9907- )....	9612-6071-01	9612-6071-02	9612-6071-01	9612-6071-02
	1	Cover 3 mm (Period -9907)....	9612-1711-01	9612-1711-02	9612-1711-01	9612-1711-02
	1	Cover 4 mm (Period 9907- )....	9612-6071-03	9612-6071-04	9612-6071-03	9612-6071-04
	1	Cover 4 mm (Period -9907)....	9612-1711-03	9612-1711-04	9612-1711-03	9612-1711-04
3	1	Seal, NBR (Standard) .....	9612-1710-04	9612-1710-04	9612-1710-04	9612-1710-04
	1	Seal, EPDM.....	9612-1710-03	9612-1710-03	9612-1710-03	9612-1710-03
	1	Seal, FPM .....	9612-1710-02	9612-1710-02	9612-1710-02	9612-1710-02
	1	Seal, Q.....	9612-1710-01	9612-1710-01	9612-1710-01	9612-1710-01
8	1	Toggle (Period 9907- ).....	9612-6067-01	9612-6067-01	9612-6067-01	9612-6067-01
	1	Toggle (Period -9907).....	9612-1707-02	9612-1707-02	9612-1707-02	9612-1707-02
9	1	Thrust plate (Period 9907- )....	9612-6075-01	9612-6075-01	9612-6075-01	9612-6075-01
	1	Thrust plate (Period -9907)....	9612-1716-01	9612-1716-01	9612-1716-01	9612-1716-01
10	1	Clamping nut (Period 9907- ) ..	9612-6077-01	9612-6077-01	9612-6077-01	9612-6077-01
	1	Clamping nut (Period -9907) ..	9612-1708-02	9612-1708-02	9612-1708-02	9612-1708-02
11	1	Clip (Period 9907- ) .....	9611-99-0704	9611-99-0704	9611-99-0704	9611-99-0704

Recommended spare parts: Pos. 3.

TD 900-226

# Oval Manhole Cover 450 x 350 Type LKDP

12



TD 501-015

## Oval Manhole Cover 450 x 350 Type LKDP


Pos.	Qty.	Denomination	With angle shaped frame and left-hand hinge		With flat frame and left-hand hinge	
			1. 4301	1. 4571	1. 4301	1. 4571
1	1	Frame 70x3.....	9612-1768-01	9612-1768-02		
	1	Frame 70x4.....	9612-1768-03	9612-1768-04		
	1	Frame 100x3.....	9612-1768-05	9612-1768-06		
	1	Frame 100x4.....	9612-1768-07	9612-1768-08		
	1	Frame 140x3.....	9612-1768-09	9612-1768-10		
	1	Frame 140x4.....	9612-1768-11	9612-1768-12		
	1	Frame 10x30.....			9612-1767-01	9612-1767-02
	1	Frame 12x30.....			9612-1767-03	9612-1767-04
2	1	Cover 3 mm (Period 9907- ).....	9612-6072-05	9612-6072-06	9612-6072-05	9612-6072-06
	1	Cover 3 mm (Period -9907).....	9612-1766-01	9612-1766-02	9612-1766-01	9612-1766-02
	1	Cover 4 mm (Period 9907- ).....	9612-6072-07	9612-6072-08	9612-6072-07	9612-6072-08
	1	Cover 4 mm (Period -9907).....	9612-1766-03	9612-1766-04	9612-1766-03	9612-1766-04
3	1	Seal, NBR (Std.).....	9612-1710-04	9612-1710-04	9612-1710-04	9612-1710-04
	1	Seal, EPDM.....	9612-1710-03	9612-1710-03	9612-1710-03	9612-1710-03
	1	Seal, FPM.....	9612-1710-02	9612-1710-02	9612-1710-02	9612-1710-02
	1	Seal, Q.....	9612-1710-01	9612-1710-01	9612-1710-01	9612-1710-01
4	1	Suspension arm.....	9612-1715-01	9612-1715-01	9612-1715-01	9612-1715-01
5	1	Hub (Period 9907- ).....	9612-6076-01	9612-6076-01	9612-6076-01	9612-6076-01
	1	Hub (Period -9907).....	9612-1718-02	9612-1718-02	9612-1718-02	9612-1718-02
6	1	Nut.....	9611-99-1761	9611-99-1761	9611-99-1761	9611-99-1761
7	2	Screw.....	9611-99-1760	9611-99-1760	9611-99-1760	9611-99-1760
8	1	Toggle (Period 9907- ).....	9612-6067-01	9612-6067-01	9612-6067-01	9612-6067-01
	1	Toggle (Period -9907).....	9612-1707-02	9612-1707-02	9612-1707-02	9612-1707-02
9	1	Thrust plate (Period 9907- ).....	9612-6075-01	9612-6075-01	9612-6075-01	9612-6075-01
	1	Thrust plate (Period -9907).....	9612-1716-02	9612-1716-02	9612-1716-02	9612-1716-02
10	1	Clamping nut (Period 9907- ).....	9612-6077-01	9612-6077-01	9612-6077-01	9612-6077-01
	1	Clamping nut (Period -9907).....	9612-1708-02	9612-1708-02	9612-1708-02	9612-1708-02
11	1	Clip (Period 9907- ).....	9611-99-0704	9611-99-0704	9611-99-0704	9611-99-0704

Recommended spare parts: Pos. 3.

TD 900-227

# Oval Manhole Cover 510 x 410 Type LKTD & LKTDI

14



TD 507-013

## Oval Manhole Cover 510 x 410 Type LKTD & LKTDI


Pos.	Qty.	Denomination	LKTD	LKTD	LKTDI	LKTDI
			1.4301 10 mm cover	1.4301 15 mm cover	1.4301 10 mm cover	1.4301 15 mm cover
1	1	Frame (Period 9907-) .....	9612-6053-01	9612-6053-01	9612-6054-01	9612-6054-01
	1	Frame (Period -9907) .....	9611-70-2003	9611-70-2003	9611-70-082-0	9611-70-082-0
2	1	Cover (Period 9907-).....	9612-6074-01	9612-6074-03	9612-6074-01	9612-6074-03
	1	Cover (Period -9907).....	9611-70-2017	9611-70-2018	9611-70-2017	9611-70-2018
3	1	Hub (Period 9907-) .....	9612-6076-02	9612-6076-02	9612-6076-02	9612-6076-02
	1	Hub (Period -9907) .....	9611-70-2038	9611-70-2038	9611-70-2038	9611-70-2038
4	1	Toggle (Period 9907-).....	9612-6065-01	9612-6065-01	9612-6066-01	9612-6066-01
	1	Toggle (Period -9907).....	9611-70-2046	9611-70-2046	9611-70-2048	9611-70-2048
5	1	Trust collar (Period 9907-) .....	9612-6075-01	9612-6075-01	9612-6075-01	9612-6075-01
	1	Trust collar (Period -9907) .....	9611-70-2055	9611-70-2055	9611-70-2055	9611-70-2055
6	1	Top nut (Period 9907-) .....	9612-6077-01	9612-6077-01	9612-6077-01	9612-6077-01
	1	Top nut (Period -9907) .....	9611-70-2050	9611-70-2050	9611-70-2050	9611-70-2050
7	2	Screw (Period 9907-) .....	9611-99-1760	9611-99-1760	9611-99-1760	9611-99-1760
	1	Bolt for hinge (Period -9907) .....	9611-70-2032	9611-70-2032	9611-70-2032	9611-70-2032
8	1	Suspension arm, left (Period 9907-).....	9612-6049-01	9612-6049-01	9612-6050-01	9612-6050-01
	1	Suspension arm, left (Period -9907).....	9611-70-2034	9611-70-2034	9611-70-085-0	9611-70-085-0
9	1	Clip (Period 9907-).....	9611-99-0704	9611-99-0704	9611-99-0704	9611-99-0704
	1	Stop screw (Period -9907) .....	9611-70-2054	9611-70-2054	9611-70-2054	9611-70-2054
10	1	Nut (Period 9907-) .....	9611-99-1761	9611-99-1761	9611-99-1761	9611-99-1761
	3	Nut (Period -9907) .....	9611-99-0211	9611-99-0211	9611-99-0211	9611-99-0211
11	1	Seal, NBR (Std.).....	9611-70-2071	9611-70-2071	9611-70-2071	9611-70-2071
	1	Seal, EPDM .....	9611-70-160-0	9611-70-160-0	9611-70-160-0	9611-70-160-0
	1	Seal, FPM .....	9611-70-160-2	9611-70-160-2	9611-70-160-2	9611-70-160-2
	1	Seal, Silicone (Q).....	9611-70-160-4	9611-70-160-4	9611-70-160-4	9611-70-160-4

Pos.	Qty.	Denomination	LKTD	LKTD	LKTDI	LKTDI
			1.4404 10 mm cover	1.4404 15 mm cover	1.4404 10 mm cover	1.4404 15 mm cover
1	1	Frame (Period 9907-).....	9612-6053-02	9612-6053-02	9612-6054-02	9612-6054-02
	1	Frame (Period -9907).....	9611-70-2144	9611-70-2144	9611-70-082-1	9611-70-082-1
2	1	Cover (Period 9907-).....	9612-6074-02	9612-6074-04	9612-6074-02	9612-6074-04
	1	Cover (Period -9907).....	9611-70-2155	9611-70-2159	9611-70-2155	9611-70-2159
3	1	Hub (Period 9907-) .....	9612-6076-02	9612-6076-02	9612-6076-02	9612-6076-02
	1	Hub (Period -9907) .....	9611-70-2038	9611-70-2038	9611-70-2038	9611-70-2038
4	1	Toggle (Period 9907-).....	9612-6065-01	9612-6065-01	9612-6066-01	9612-6066-01
	1	Toggle (Period -9907).....	9611-70-2046	9611-70-2046	9611-70-2048	9611-70-2048
5	1	Trust collar (Period 9907-) .....	9612-6075-01	9612-6075-01	9612-6075-01	9612-6075-01
	1	Trust collar (Period -9907) .....	9611-70-2055	9611-70-2055	9611-70-2055	9611-70-2055
6	1	Top nut (Period 9907-) .....	9612-6077-01	9612-6077-01	9612-6077-01	9612-6077-01
	1	Top nut (Period -9907) .....	9611-70-2050	9611-70-2050	9611-70-2050	9611-70-2050
7	2	Screw (Period 9907-).....	9611-99-1760	9611-99-1760	9611-99-1760	9611-99-1760
	1	Bolt for hinge (Period -9907) .....	9611-70-2032	9611-70-2032	9611-70-2032	9611-70-2032
8	1	Suspension arm, left (Period 9907-).....	9612-6049-01	9612-6049-01	9612-6050-01	9612-6050-01
	1	Suspension arm, left (Period -9907).....	9611-70-2034	9611-70-2034	9611-70-085-0	9611-70-085-0
9	1	Clip (Period 9907-).....	9611-99-0704	9611-99-0704	9611-99-0704	9611-99-0704
	1	Stop screw (Period -9907) .....	9611-70-2054	9611-70-2054	9611-70-2054	9611-70-2054
10	1	Nut (Period 9907-) .....	9611-99-1761	9611-99-1761	9611-99-1761	9611-99-1761
	3	Nut (Period -9907) .....	9611-99-0211	9611-99-0211	9611-99-0211	9611-99-0211
11	1	Seal, NBR (Std.).....	9611-70-2071	9611-70-2071	9611-70-2071	9611-70-2071
	1	Seal, EPDM .....	9611-70-160-0	9611-70-160-0	9611-70-160-0	9611-70-160-0
	1	Seal, FPM .....	9611-70-160-2	9611-70-160-2	9611-70-160-2	9611-70-160-2
	1	Seal, Silicone (Q).....	9611-70-160-4	9611-70-160-4	9611-70-160-4	9611-70-160-4

Recommended spare parts: Pos. 11.

# Manhole Cover Type LKDC

16





## Manhole Cover Type LKDC


Pos.	Qty.	Denomination	DN 200	DN 300	DN 430	DN 500	DN 620
1	1	Frame 85 mm (1.4301).....	9612-3435-01				
	1	Frame 85 mm (1.4404).....	9612-3435-02				
	1	Frame 100 mm (1.4301).....			9611-70-054-0	9611-70-127-0	9612-4982-01
	1	Frame 100 mm (1.4404).....			9611-70-054-1	9611-70-127-1	9612-4982-02
	1	Frame 150 mm (1.4301).....		9612-3442-01			
	1	Frame 150 mm (1.4404).....		9612-3442-02			
	1	Frame 200 mm (1.4301).....			9611-70-409-1	9611-70-412-1	9612-4982-03
	1	Frame 200 mm (1.4404).....			9611-70-409-2	9611-70-412-2	9612-4982-04
2	1	Cover (1.4301) .....	9612-3433-01	9612-3440-01	9611-70-210-2	9611-70-129-0	9612-4980-02
	1	Cover (1.4404) .....	9612-3433-02	9612-3440-02	9611-73-210-2	9611-70-129-1	9612-4980-01
3	1	Toggle .....	9612-3437-01	9612-3444-01	9611-70-056-0	9611-70-131-0	9612-4978-01
4	1	Swing bolt .....	9611-70-059-0	9611-70-059-0	9611-70-059-0	9611-70-059-0	9611-70-059-0
5	1	Handle, blue (Per. 9907-).....	9611-70-063-2	9611-70-063-2	9611-70-063-2	9611-70-063-2	9611-70-063-2
	1	Handle, green (Per. -9907) .....	9611-70-063-0	9611-70-063-0	9611-70-063-0	9611-70-063-0	9611-70-063-0
6	1	Capsule, blue (Per. 9907-).....	9611-70-064-4	9611-70-064-4	9611-70-064-4	9611-70-064-4	9611-70-064-4
	1	Capsule, green (Per. -9907).....	9611-70-064-0	9611-70-064-0	9611-70-064-0	9611-70-064-0	9611-70-064-0
7	1	Seal, NBR (Standard) .....	9612-3179-01	9612-3180-01	9611-70-045-0	9611-70-125-0	9612-5128-02
	1	Seal, EPDM.....	9612-3179-02	9612-3180-02	9611-70-045-1	9611-70-125-1	9612-5128-01
	1	Seal, FPM .....	9612-3179-03	9612-3180-03	9611-70-045-2	9611-70-125-2	9612-5128-03
8	3	Pin .....	9611-70-210-5	9611-70-210-5	9611-70-210-5	9611-70-210-5	9611-70-210-5
9	6	Lock ring, EPDM .....	9611-99-3309	9611-99-3309	9611-99-3309	9611-99-3309	9611-99-3309
10	1	Connex-pin .....	9611-99-0561	9611-99-0561	9611-99-0561	9611-99-0561	9611-99-0561

Recommended spare parts: Pos. 7.

TD 900-229

# Round Dust Manhole Cover Type LKDS

18



## Round Dust Manhole Cover Type LKDS


Pos.	Qty.	Denomination	9611-70-097-0 20 mm Frame 1.4301	9611-70-097-1 20 mm Frame 1.4404
1	1	Cover .....	32010-1290-1	32010-1290-2
2	1	Frame 20 mm .....	32010-0764-1	32010-0764-2
3	1	Left hinge ear .....	32010-0918-1	32010-0918-1
4	1	Right hinge ear .....	32010-0919-1	32010-0919-1
5	1	Pin for handle .....	32010-0761-1	32010-0761-1
6	2	O-ring .....	9611-99-2677	9611-99-2677
7	1	Ball handle .....	9612-2899-01	9612-2899-01

Pos.	Qty.	Denomination	9612-1726-01 100 mm Frame 1.4301	9612-1726-02 100 mm Frame 1.4404
1	1	Cover .....	32010-1290-1	32010-1290-2
2	1	Frame 100 mm .....	9612-1727-01	9612-1727-02
3	1	Left hinge ear .....	9612-3590-02	9612-3590-02
4	1	Right hinge ear .....	9612-3590-01	9612-3590-01
5	1	Pin for handle .....	32010-0761-1	32010-0761-1
6	2	O-ring .....	9611-99-2677	9611-99-2677
7	1	Ball handle .....	9612-2899-01	9612-2899-01

TD 900-231

# Manhole Cover Type HLSD

20



# Manhole Cover Type HLSD

Pos.	Qty.	Denomination	
1	1	Nut.....	221891-15
2	1	Screw .....	9611-99-2790
3	1	Ball handle .....	9611-99-1970
5		Handle (plast).....	9611-70-067-1
		Handle (steel).....	9612-5600-01
6		Hub DN200-DN800 .....	9612-1747-01
7		Spring .....	9612-1751-01
8		Pin .....	9612-1750-01
9		Swing bolt.....	9612-1739-01
10		Ring pin .....	9611-99-2843

Pos.	Qty.	Denomination	ø200	ø300	ø400	ø450
4	1	Seal - silicone (Q) .....	9611-99-2862	9611-99-2867	9611-99-2054	9611-99-2059
	1	Seal - EPDM .....	9611-99-2137	9611-99-2868	9611-99-2055	9611-99-2060
	1	Seal - FPM.....	9611-99-2138	9611-99-2869	9611-99-2056	9611-99-2061
	1	Seal - NBR.....	9611-99-2139	9611-99-2870	9611-99-2057	9611-99-2062
	1	Seal - FEP.....	9611-99-2866	9611-99-2871	9611-99-2058	9611-99-2063

Pos.	Qty.	Denomination	ø500	ø620	ø800
4	1	Seal - silicone (Q) .....	9611-99-2064	9611-99-2069	9611-99-2872
	1	Seal - EPDM .....	9611-99-2065	9611-99-2070	9611-99-2873
	1	Seal - FPM.....	9611-99-2066	9611-99-2071	9611-99-2874
	1	Seal - NBR.....	9611-99-2067	9611-99-2072	9611-99-2875
	1	Seal - FEP.....	9611-99-2068	9611-99-2073	9611-99-2876

Recommended spare Parts: Pos. 4.

TD 900-232

**How to contact Alfa Laval**

Contact details for all countries are continually updated on our website. Please visit [www.alfalaval.com](http://www.alfalaval.com) to access the information direct.

The information contained herein is correct at the time of issue but may be subject to change without prior notice.