




Spare Parts

Tank Accessories - LKTC, LKS and LKL

Tank Leg with Base Plate
Type LKTC

2




Tank Leg with Base Plate Type LKTC

AISI 304

Pos.	Qty.	Denomination	9611-71-022-0 19 mm	9611-71-023-0 25 mm	9611-71-025-0 38 mm
1	1	Nut	9611-71-035-0	9611-71-038-0	9611-71-041-0
2	1	Foot - solid	9611-71-036-0	9611-71-039-0	9611-71-042-0
3	1	Base plate	9611-71-037-0	9611-71-040-0	9611-71-043-0

Tank Sight Glass Type LKS

4



Tank Sight Glass Type LKS


AISI 316

Pos.	Qty.	Denomination	9611-71-0101 Dia. 78 mm	9611-71-0102 Dia. 120 mm
1	1	Welding flange	9611-71-2029	9611-71-2010
2	1	Nut	9611-71-2030	9611-71-2011
3Δ	1	Seal	9611-99-0101	9611-99-0102
4Δ	1	Seal (NBR)	9611-99-0103	9611-99-0104
5Δ	1	Glass plate	9611-99-0501	9611-99-0502
Δ		Service kit	9611-92-5002	9611-92-5003

Parts marked with Δ are included in the **Service kit**.

Light Fitting
Type LKL

6



**Light Fitting
Type LKL**

AISI 304

Pos.	Qty.	Denomination	9611-71-142-0 Dia. 78 mm	9611-71-143-0 Dia. 120 mm
1	1	Cover	9611-71-0003	9611-71-0004
2	1	Socket (China)	9611-99-0815	9611-99-0815

How to contact Alfa Laval
Contact details for all countries are
continually updated on our website.
Please visit www.alfalaval.com to
access the information direct.