






## Spare Parts

### *Unique* Single Seat Valve - Long Stroke



**Unique Single Seat Valve - Long Stroke**  
**Shut-off valve - 38-101.6 mm/DN40-100**

Drawing



Pos.	Qty	Denomination	DN 40 38 mm	DN 50 51 mm	DN65 63.5 mm	DN 80 76.1 mm	DN 100 101.6 mm
<b>Actuator</b>							
		Actuator, complete (NO).....	9613-1548-16	9613-1548-17	9613-1548-18	9613-1548-19	9613-1548-20
		Actuator, complete (NC).....	9613-1548-21	9613-1548-22	9613-1548-23	9613-1548-24	9613-1548-25
		Actuator, complete (A/A).....	9613-1548-26	9613-1548-27	9613-1548-28	9613-1548-29	9613-1548-30
	5	Adapter.....	9613-1274-01	9613-1274-01	9613-1274-01	9613-1274-01	9613-1274-01
	□ 6	Bushing.....					
	□ 7	O-ring.....					
	□ 8	O-ring.....					
	9	Plug.....	9613-4141-01	9613-4141-01	9613-4141-01	9613-4141-01	9613-4141-01
	12	1(2) Air fitting.....	9611-99-1988	9611-99-1988	9611-99-1988	9611-99-1988	9611-99-1988
<b>Clamp</b>							
	19	1 Clamp.....	9612-9393-03	9612-9393-04	9612-9393-05	9612-9393-06	9612-9393-07
<b>Bonnet</b>							
	20	1 Bonnet.....	9613-1271-02	9613-1271-03	9613-1271-04	9613-1271-05	9613-1271-06
	◆ 21	1 O-ring, EPDM (Standard).....					
		1 O-ring, HNBR.....					
		1 O-ring, FPM.....					
	24	1 Bushing.....	9613-1250-02	9613-1250-02	9613-1250-02	9613-1250-02	9613-1250-02
	◆ 25	1 Lip seal, EPDM (Standard).....					
		1 Lip seal, HNBR.....					
		1 Lip seal, FPM.....					
<b>Valve Body</b>							
	22	1 Valve body, lower, 2 ports ISO.....	9613-1395-03	9613-1395-05	9613-1395-07	9613-1395-09	9613-1395-11
		1 Valve body, lower, 3 ports ISO.....	9613-1395-04	9613-1395-06	9613-1395-08	9613-1395-10	9613-1395-12
		1 Valve body, lower, 2 ports DIN.....	9613-1396-03	9613-1396-05	9613-1396-07	9613-1396-09	9613-1396-11
		1 Valve body, lower, 3 ports DIN.....	9613-1396-04	9613-1396-06	9613-1396-08	9613-1396-10	9613-1396-12
<b>Valve Plug</b>							
	23	1 Plug, shut off, ISO/DIN, complete, EPDM.....	9613-1619-02	9613-1619-03	9613-1619-04	9613-1619-05	9613-1619-06
		(standard)					
		1 Plug, shut off, ISO/DIN, complete, HNBR.....	9613-1619-08	9613-1619-09	9613-1619-10	9613-1619-11	9613-1619-12
		1 Plug, shut off, ISO/DIN, complete, FPM.....	9613-1619-14	9613-1619-15	9613-1619-16	9613-1619-17	9613-1619-18
	23.1	1 Plug, shut off, ISO/DIN.....	9613-1590-01	9613-1591-01	9613-1592-01	9613-1593-01	9613-1398-06
	◆ 23.2	1 Plug seal, EPDM (Standard).....					
		1 Plug seal, HNBR.....					
		1 Plug seal, FPM.....					
<b>Recommended spare parts: Service kits.</b>							
	□	Service kit, actuator.....	9611-92-6500	9611-92-6500	9611-92-6500	9611-92-6500	9611-92-6500
	◆	Service kit, EPDM.....	9611-92-6502	9611-92-6503	9611-92-6504	9611-92-6505	9611-92-6506
	◆	Service kit, HNBR.....	9611-92-6508	9611-92-6509	9611-92-6510	9611-92-6511	9611-92-6512
	◆	Service kit, FPM.....	9611-92-6514	9611-92-6515	9611-92-6516	9611-92-6517	9611-92-6518


Parts marked with □ are included in the service kits (actuator)

Parts marked with ◆ are included in the service kits (product wetted parts)

Tool for bushing (pos. 24) 9613-1609-01

**Unique Single Seat Valve - Long Stroke  
Change-over Valve - 38-101.6 mm/DN40-100**

Drawing



Pos.	Qty	Denomination	DN 40 38 mm	DN 50 51 mm	DN65 63.5 mm	DN 80 76.1 mm	DN 100 101.6 mm
<b>Actuator</b>							
		Actuator, complete (NO).....	9613-1548-16	9613-1548-17	9613-1548-18	9613-1548-19	9613-1548-20
		Actuator, complete (NC).....	9613-1548-21	9613-1548-22	9613-1548-23	9613-1548-24	9613-1548-25
		Actuator, complete (A/A).....	9613-1548-26	9613-1548-27	9613-1548-28	9613-1548-29	9613-1548-30
	5	Adapter.....	9613-1274-01	9613-1274-01	9613-1274-01	9613-1274-01	9613-1274-01
	□ 6	Bushing.....					
	□ 7	O-ring.....					
	□ 8	O-ring.....					
	9	Plug.....	9613-4141-01	9613-4141-01	9613-4141-01	9613-4141-01	9613-4141-01
	12	1(2) Air fitting.....	9611-99-1988	9611-99-1988	9611-99-1988	9611-99-1988	9611-99-1988
<b>Clamp</b>							
	19	2 Clamp.....	9612-9393-03	9612-9393-04	9612-9393-05	9612-9393-06	9612-9393-07
<b>Bonnet</b>							
	20	1 Bonnet.....	9613-1271-02	9613-1271-03	9613-1271-04	9613-1271-05	9613-1271-06
	◆ 21	1 O-ring, EPDM (Standard).....					
		1 O-ring, HNBR.....					
		1 O-ring, FPM.....					
	24	1 Bushing.....	9613-1250-02	9613-1250-02	9613-1250-02	9613-1250-02	9613-1250-02
	◆ 25	1 Lip seal, EPDM (Standard).....					
		1 Lip seal, HNBR.....					
		1 Lip seal, FPM.....					
	28	1 Seat.....	9613-1275-02	9613-1275-03	9613-1275-04	9613-1275-05	9613-1275-06
<b>Valve Body</b>							
	26	1 Valve body, upper, 1 port ISO.....	9613-1393-03	9613-1393-05	9613-1393-07	9613-1393-09	9613-1393-11
		1 Valve body, upper, 2 ports ISO.....	9613-1393-04	9613-1393-06	9613-1393-08	9613-1393-10	9613-1393-12
		1 Valve body, upper, 1 port DIN.....	9613-1394-03	9613-1394-05	9613-1394-07	9613-1394-09	9613-1394-11
		1 Valve body, upper, 2 ports DIN.....	9613-1394-04	9613-1394-06	9613-1394-08	9613-1394-10	9613-1394-12
	22	1 Valve body, lower, 2 ports ISO.....	9613-1395-03	9613-1395-05	9613-1395-07	9613-1395-09	9613-1395-11
		1 Valve body, lower, 3 ports ISO.....	9613-1395-04	9613-1395-06	9613-1395-08	9613-1395-10	9613-1395-12
		1 Valve body, lower, 2 ports DIN.....	9613-1396-03	9613-1396-05	9613-1396-07	9613-1396-09	9613-1396-11
		1 Valve body, lower, 3 ports DIN.....	9613-1396-04	9613-1396-06	9613-1396-08	9613-1396-10	9613-1396-12
<b>Valve Plug</b>							
	27	1 Plug, change over, ISO/DIN complete, EPDM ... (standard)	9613-1620-02	9613-1620-03	9613-1620-04	9613-1620-05	9613-1620-06
		1 Plug, change over, ISO/DIN complete, HNBR ...	9613-1620-08	9613-1620-09	9613-1620-10	9613-1620-11	9613-1620-12
		1 Plug, change over, ISO/DIN complete, FPM.....	9613-1620-14	9613-1620-15	9613-1620-16	9613-1620-17	9613-1620-18
	27.1	1 Plug, change over, ISO/DIN .....	9613-1594-01	9613-1595-01	9613-1596-01	9613-1597-01	9613-1598-01
	◆ 27.2	1 Plug seal, EPDM (Standard).....					
		1 Plug seal, HNBR.....					
		1 Plug seal, FPM.....					
<b>Recommended spare parts: Service kits.</b>							
	□	Service kit, actuator.....	9611-92-6500	9611-92-6500	9611-92-6500	9611-92-6500	9611-92-6500
	◆	Service kit, EPDM.....	9611-92-6580	9611-92-6581	9611-92-6582	9611-92-6583	9611-92-6584
	◆	Service kit, HNBR.....	9611-92-6586	9611-92-6587	9611-92-6588	9611-92-6589	9611-92-6590
	◆	Service kit, FPM.....	9611-92-6592	9611-92-6593	9611-92-6594	9611-92-6595	9611-92-6596

Parts marked with □ are included in the service kits (actuator)

Parts marked with ◆ are included in the service kits (product wetted parts)

Tool for bushing (pos. 24) 9613-1609-01

TD 900-334/1

**How to contact Alfa Laval**

Contact details for all countries are continually updated on our website. Please visit [www.alfalaval.com](http://www.alfalaval.com) to access the information direct.